# FR High Performance Series Garments Sizing Charts

#### MEN'S HIGH PERFORMANCE FR GARMENT SIZING

High Performance FR Series Knits and Shirts													
	S	М	L	XL	2X	3X	4X	5X	6X				
Chest	36-38	40-42	44-46	48-50	52-54	56-58	60-62	64-66	68-70				
Sleeve	35	36	36.5	37	38	39	40	41	42				

Tall sizes MT-4XT add 2" to the standard sleeve length, 2" to the body.

High Performance FR Series Hoodies and Jackets													
	XS S M L XL 2XL 3XL 4XL												
Chest	32-34	36-38	40-42	44-46	48-50	52-54	56-58	60-62	64-66				
Sleeve	33	34	35	36.5	38	39	40	41.5	43				

### WOMEN'S HIGH PERFORMANCE FR SHIRT SIZING

High Performance FR Series Knits and DH Shirts													
	X/S	S	М	L XL		2X	3X	4X					
Fits	1/2	4/6	8/10	12/14	16/18	20/22	24/26	28/30					

Tall sizes M-3X

## MENS/WOMEN'S HIGH PERFORMANCE FR PANT SIZING

<b>FR Pants</b>															
	4XS 3XS 2XS XS SM MD L XL 2XL 3XL 4XL 5XL 6XL														
Women's Waist Sizes	0	2	4	6	8	10	12	14	16	18	20	22	24	26	28
Men's Waist Sizes	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Inseams available in even sizes from 28-34

#### No Need to Size Up to Layer Up!

If you buy a base/mid/outer combo and need a Size Large base, you order **Large** for all layers.

No need to guess and get an up-sized outer garment fit over your layered system!



